Mast range

HEB profiles 200-260

When ordering, state number of rod guides (2 or 3), and also the mast size and mast position (normal = N, turned = V). In the case of motor drive, a metal cover is available on request for cable protection.

For 2 field sectioning point: 4 long shank bolts 3251 order seprately

Fasteners

Supplied complete with U-bolts.

Drawing number 561.00596

Ordering information

2 rod guides 1 mast HEB 220 normal 1 mast HEB 220 normal 1 mast HEB 220 normal 7642.2.22N.22N Gantry for 5-switch sectioning point 1,5 - 3,6 kV

